

1 **Activate the Dry-Brik®** by removing the foil cover. Do not remove the foil cover until you are ready to use the Dry-Brik. Once the foil cover is removed, the Dry-Brik will begin adsorbing moisture.



2 **Write the date** that this Dry-Brik is placed in service.

Write the date here.



3 **Replace the Dry-Brik after 2 months.** Dispose of the old one in household refuse.



dryandstore.com

DRY-BRIK® III

Write today's date here: _____

DISCARD AFTER 2 MONTHS

2ヶ月 2 måneder 2 mois
2個月 2 Monate 2 meses

